

PRO-LIFT SOFA BED FITTINGS WITH GUIDE

Special Features

- Specially designed Pro-lift sofa cum bed fitting with guide to convert your sofa into bed.
- Comes with in-built sliding mechanism.
- Min. depth: 845mm
- Max. height: 295mm
- Max. Width: 1524 - 1828.8mm

Specifications

Code No.	Finish
PLSB1-G	AT



Fitting Instructions

1. Fix the Guide track to the side walls of the sofa as shown in Fig.1.
2. Screw the stopper bush onto the guide track as shown in Fig.2.
3. Slide in the fittings into the guide track from back side as shown in Fig.3.
4. Fix the moving bracket onto the bed cushion as shown in Fig.4.
5. Fit the front fascia onto the fascia bracket as shown in Fig.5.

